



1 - Open the box included the insulation shell



2 - Install back half of insulation shell



3 - Install front half of insulation shell



4 - Use the included (2) inspection stickers to secure both halves of the shell together



5 - PTM insulator installed



6 - Make sure the warning label is visible